



## **General Information**

<b>Chassis and Paint Codes .....</b>	<b>1-2</b>
<b>Identification Number Locations .....</b>	<b>1-8</b>
<b>Warning/Caution Label Locations .....</b>	<b>1-9</b>
<b>Under-hood Emissions Control</b>	
<b>Label .....</b>	<b>1-14</b>
<b>Lift and Support Points</b>	
<b>Lift and Safety Stands .....</b>	<b>1-17</b>
<b>Floor Jack .....</b>	<b>1-18</b>
<b>Towing .....</b>	<b>1-19</b>
<b>Service Precautions</b>	
<b>Parts Marking Locations .....</b>	<b>1-20</b>