

GENERAL INFORMATION

00
SECTION

00-00

GENERAL INFORMATION . . . 00-00

00-00 GENERAL INFORMATION

HOW TO USE THIS MANUAL	00-00-1	Dynamometer	00-00-16
Range of Topics	00-00-1	INSTALLATION OF RADIO SYSTEM	00-00-16
Service Procedure	00-00-2	ELECTRICAL SYSTEM	00-00-16
Symbols	00-00-3	Electrical Parts	00-00-16
Advisory Messages	00-00-4	Wiring Harness	00-00-17
Troubleshooting Procedure	00-00-5	Connectors	00-00-17
Procedures for Use	00-00-6	Terminals	00-00-18
UNITS	00-00-11	Sensors, Switches, and Relays	00-00-19
Conversion to SI Units (Système International d'Unités)	00-00-11	Wiring Harness	00-00-19
Rounding Off	00-00-11	Fuse	00-00-19
Upper and Lower Limits	00-00-11	Electrical Troubleshooting Tools	00-00-20
FUNDAMENTAL PROCEDURES	00-00-11	Precautions Before Welding	00-00-20
Protection of the Vehicle	00-00-11	JACKING POSITIONS	00-00-21
Preparation of Tools and Measuring Equipment	00-00-12	Front	00-00-21
Special Service Tools	00-00-12	Rear	00-00-21
Oil Leakage Inspection	00-00-12	VEHICLE LIFT (2 SUPPORTS) AND SAFETY	
Disconnection of the Negative Battery Cable	00-00-13	STAND (RIGID RACK) POSITION	00-00-22
Removal of Parts	00-00-13	Vehicle Lift Positions	00-00-22
Disassembly	00-00-13	Safety Stand Positions	00-00-22
Inspection During Removal, Disassembly	00-00-13	TOWING	00-00-22
Arrangement of Parts	00-00-14	Tiedown Hooks	00-00-23
Cleaning of Parts	00-00-14	IDENTIFICATION NUMBER LOCATIONS 00-00-24	
Reassembly	00-00-14	Vehicle Identification Number (VIN)	00-00-24
Adjustment	00-00-15	Chassis Number	00-00-24
Rubber Parts and Tubing	00-00-15	Engine Identification Number	00-00-24
Hose Clamps	00-00-15	SAE STANDARDS	00-00-25
Torque Formulas	00-00-15	ABBREVIATIONS	00-00-26
Vise	00-00-16	PRE-DELIVERY INSPECTION	00-00-27
		Pre-Delivery Inspection Table	00-00-27
		SCHEDULED MAINTENANCE	00-00-29
		Scheduled Maintenance Table	00-00-29

HOW TO USE THIS MANUAL

A3U000000001W01

Range of Topics

- This manual contains procedures for performing all required service operations. The procedures are divided into the following five basic operations:
 - Removal/Installation
 - Disassembly/Assembly
 - Replacement
 - Inspection
 - Adjustment
- Simple operations which can be performed easily just by looking at the vehicle (i.e., removal/installation of parts, jacking, vehicle lifting, cleaning of parts, and visual inspection) have been omitted.