

Quick Reference Guide

General Information	1
Fuel System	2
Engine Lubrication System	3
Exhaust System	4
Engine Top End	5
Engine Removal and Installation	6
Engine Bottom End	7
Cooling and Bilge Systems	8
Drive System	9
Pump and Impeller	10
Steering	11
Hull / Engine Hood	12
Electrical System	13
Storage	14
Appendix	15

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.